All Plastic

NEMA 4X

Enclosure

Built in

Visual Alarm





Features

- High Intensity Red Alarm Light
- Pulse to Relay Output
- **⊘** Super Loud 108dB Audible Alarm
- Silence Function | Light Remains On
- **Output** Rugged NEMA 4X Industrial Enclosure
- External Wall Mounting Brackets
- **Object of the Proof of the Pro**
- Includes 6' Power Cord + Watertight Cord
- Completely Pre-Wired
 - Extra Output Contact to Remote Alarm or PLC


















Alarm Test



3 Easy Mounting Options





Panel Mount



Pole/Pipe Mount



23-0082

ProAlert® 2

Industrial Visual | Audible Sentry Alarm




Typical Applications

- High High | Low Level Indication for Tanks | Sumps
- **⊘** Bag | Filter Change Out
- Leak Detection
- ✓ Flow | No Flow Sensors | Pump Protection
- Upset Condition Notification

Specifications

- **⊘** Enclosure | NEMA 4X
- Weight | 2.1 lbs.
- ✓ Input Power | 100 240VAC



NOTE: The ProAlert® PA223 can be used in more than just leak detection applications. It is an excellent high/low level alarm or any other upset condition.


Model Selection

ProAlert® PA223

· 24VDC - Dry Contact Input

ProAlert® PA223-PR


- · PNP | NPN Pulse
- · Input 5AMP Relay Timer Signal Output




23-0082

Industrial Visual | Audible Sentry Alarm











VERIFY REV LEVEL OF PAPER COPY WITH REV LEVEL ON PPC WEB SITE INFORMATION SUBJECT TO CHANGE WITHOUT NOTICE NON-CONTROLLED COPY



Poly Processing Leak Detection System Wiring with Quick Connect on Pro-Alert 1000 PA223

Inside the Pro-Alert 1000 box the P2R Relay has been prewired to a quick connect which the LDS-YN-Leak Sensor will connect to.



From the LDS-YN Sensor there is a Blue, Black, and Brown wire and they should attach as follows:

- 1. Blue sensor wire will connect to the Blue quick connect terminal.
- 2. Black sensor wire will connect to the Yellow quick connect terminal.
- 3. Brown sensor wire will connect to the Orange quick connect terminal.



4.

Troubleshooting:

If the sensor is not working properly follow the following steps:

- 1. If sensor is in constant state of alarm
 - a. Place sensor 4" above a cup of water and turn the potentiometer until the system quits alarming. This will calibrate the sensor to detect a liquid 4" from contact.
- 2. This unit does not provide a 120v output to run to a PLC/Skada system. It only provides a 12-14v output.