## SAFE-SURGE® EMERGENCY AIR SURGE PROTECTION

## To install:

- 1. SAFE-Surge® lids are HEAVY. Use lifting equipment to place the SAFE-Surge® lid over the tank manway.
- 2. Rotate the lid until the warning label is next to the edge of the tank.
- 3. Secure the lid with the polyethylene bolts provided.
- 4. Make certain the movement of the center cap of the lid is unrestricted and able to open to relieve pressure build-up in the tank.



<u>WARNING:</u> SAFE-Surge® lids are heavy (22 lbs.) and awkward! DO NOT attempt to use a ladder for installing the SAFE-Surge® lid. The ladder may become unstable and lead to a fall or injury! Use lift equipment appropriate for work environment or use scaffolding and hoisting equipment.